



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co., Ltd

Window initialization Function List V16.05

Automaker	Type1	Type2	Type3	Type4
China model	Baojun	Manual method		
China model	Beijing Hyundai	Manual method	Elantra 1.6MT	
China model	Pentium	Manual method	B50 2013 paragraph	
China model	Pentium	Manual method	other	
China model	BYD	Manual method	Speed sharp	
China model	Dongfeng Peugeot	Manual method	307	
China model	Dongfeng Fengshen	Manual method	S30	
China model	Dongfeng Nissan	Manual method	Sylphy	
China model	Dongfeng Nissan	Manual method	Junyi	
China model	Dongfeng Citroen	Manual method	Picasso	
China model	Dongfeng Citroen	Manual method	Senna	
China model	Dongfeng Citroen	Manual method	C5	
China model	Dongfeng Citroen	Manual method	C2	
China model	Guangzhou Automobile Chuanqi	Manual method	GS4	
China model	Jeep	Manual method	commander 2007	
China model	Jianghuai	Manual method	Bin Yue	
China model	Na Zhijie	Manual method	Big 7 SUV	
China model	Chery	Manual method	Types of 1	
China model	Chery	Manual method	G5	
China model	Chery	Manual method	Types of 2	
China model	Chery	Manual method	E3 2013-2014	
China model	FAW	Manual method	Wei Zhi	
China model	FAW	Manual method	Xiali	
China model	a Toyota	Manual method	Crown	
China model	FAW Mazda	Manual method	horse 6	
China model	Changan Ford	Manual method	New carnival	
China model	ZHONGHUA	Manual method	Junjie	
China model	Roewe	Manual method	350	

China model	Roewe	Manual method	550	
BENZ(Mercedes)	Manual method	W220 or S320		
BENZ(Mercedes)	Manual method	M level -W164		
BENZ(Mercedes)	Manual method	S level -221		
BENZ(Mercedes)	Software method	Automatic scanning		
BENZ(Mercedes)	Software method	Manual selection	164 - ML series	
BENZ(Mercedes)	Software method	Manual selection	X164 - GL series	
BENZ(Mercedes)	Software method	Manual selection	203 - C series (2003.08 before)	
BENZ(Mercedes)	Software method	Manual selection	204 - C series	
BENZ(Mercedes)	Software method	Manual selection	X204 - GLK series	
BENZ(Mercedes)	Software method	Manual selection	209 - CLK series (2004.03 before)	
BENZ(Mercedes)	Software method	Manual selection	212 - E series	
BENZ(Mercedes)	Software method	Manual selection	215 - CL series (2002.08 before)	
BENZ(Mercedes)	Software method	Manual selection	215 - CL series (2002.09 after)	
BENZ(Mercedes)	Software method	Manual selection	218 - CLS series	
BENZ(Mercedes)	Software method	Manual selection	220 - S series (2002.08 before)	
BENZ(Mercedes)	Software method	Manual selection	220 - S series (2002.09 after)	
BENZ(Mercedes)	Software method	Manual selection	251 - R series	
BMW	Manual method	5 system		
BMW	Manual method	X3 E83		
BMW	Manual method	other		
BMW	Software method	Automatic scanning		
BMW	Software method	Manual selection	1 series	E81/E82/E87/E88
BMW	Software method	Manual selection	1 series	F20/F21
BMW	Software method	Manual selection	2 series	F22/F23
BMW	Software method	Manual selection	3 series	E90/E91/E92/E93
BMW	Software method	Manual selection	3 series	F30/F31/F34/F35
BMW	Software method	Manual selection	4 series	F32/F33
BMW	Software method	Manual selection	5 series	E60/E61
BMW	Software method	Manual selection	5 series	F07

BMW	Software method	Manual selection	5 series	F10/F11/F18
BMW	Software method	Manual selection	6 series	E63/E64
BMW	Software method	Manual selection	6 series	F06/F12/F13
BMW	Software method	Manual selection	7 series	E65/E66/E68
BMW	Software method	Manual selection	7 series	F01/F02/F04
BMW	Software method	Manual selection	I series	I01/I12
BMW	Software method	Manual selection	X series	X1 E84
BMW	Software method	Manual selection	X series	X3 F25
BMW	Software method	Manual selection	X series	X4 F26
BMW	Software method	Manual selection	X series	X5 E70
BMW	Software method	Manual selection	X series	X5 F15
BMW	Software method	Manual selection	X series	X6 E71
BMW	Software method	Manual selection	X series	X6 E72
BMW	Software method	Manual selection	Z series	Z4 E89
BMW	Software method	Manual selection	M series	M3 E93
BMW	Software method	Manual selection	M series	M5 E60
BMW	Software method	Manual selection	M series	M6 E63/E64
BMW	Software method	Manual selection	M series	M6 F6
BMW	Software method	Manual selection	MINI	R55/R56/R57/R58/R59/R60/R61
BMW	Software method	Manual selection	MINI	F56
CHRYSLER	Manual method			
CHRYSLER	Software method	Sunroof initialization		
VOLVO	Manual method	C30		
HONDA	Manual method	New fit		
HONDA	Manual method	CR-V		
HONDA	Manual method	Honda sedan		
VW	Manual method	Types of 1-MD2 Motor		
VW	Manual method	Types of 2-MD4 Motor		
VW	Manual method	Lang Yi		
VW	Manual method	Golf 6		
VW	Manual method	Polo		
VW	Manual method	Jetta		
TOYOTA	Manual method	Crown / Reiz		
TOYOTA	Manual method	Crown 3.0		
TOYOTA	Manual method	Prado / overbearing		

TOYOTA	Manual method	Camry		
TOYOTA	Manual method	Camry 2003		
TOYOTA	Manual method	Camry		
FORD	Manual method	Mondeo		
FORD	Manual method	Mondeo 2.5L		
FORD	Manual method	Ford sedan		
CITROEN	Manual method			
NISSAN	Manual method	demeanor A33		
NISSAN	Manual method	Noble 42/ Scorpio / Qi Jun / Sima		
NISSAN	Manual method	Xintian		
RENAULT	Manual method			
MITSUBISHI	Manual method	Pajero		
MITSUBISHI	Manual method	Jin Xuan		
MITSUBISHI	Manual method	Outlander		
MITSUBISHI	Manual method	Glandi MPV		
SUZUKI	Manual method	Amagatarai SX4		
SUZUKI	Manual method	antelope		
SUBARU	Manual method			
PORSCHE	Manual method	Panamera		
PORSCHE	Manual method	911		
PORSCHE	Manual method	Cayenne -2010		
MAZDA	Manual method	RX8		
MAZDA	Manual method	horse 6/ horse 3		
MAZDA	Manual method	M6		
MAZDA	Manual method	Ruiyi		
LANDROVER	Manual method	Find 4 2010-2014		
LANDROVER	Manual method	Range Rover 2009-2012		
LANDROVER	Manual method	Find 4 2010		
LANDROVER	Manual method	Range Rover 2014-		
LANDROVER	Manual method	Freelander 2006-2011		
LANDROVER	Manual method	Find 3 2005-2009		
LANDROVER	Manual method	Freelander 2 2010-2014		
ROLLS-ROYCE	Manual method			
FIAT	Manual method			
BUICK	Manual method	Boulevard		

BUICK	Manual method	Laojun Yue		
BUICK	Manual method	Jun Yue		
BUICK	Manual method	350		
BUICK	Manual method	550		
JAGUAR	Manual method	XF 2012-2014		
JAGUAR	Manual method	XJ 2012-2014		

XTOOL