# OBDII Function list

**Notes:**

| | |
|---|---|
| √ | Functions marked with √ is fully supported and already exited in former software version. |
| * | Functions marked with * is fully supported and newly added in current software version. |
| # | Functions marked with # is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcle models or systems. |
| | Functions left with blank is not supported. |

| vehicle | Read Codes | Erase Codes | Vehicle Information | Live Data | Freeze Frame | Component Test | On-Board Monitor Test | O2S Monitoring Test | I/M Readiness | Stored Codes | Pending Codes | Permanent Codes |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| OBDII | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |

XTOOL